



# GRAM

SERIES

**C9**



USER MANUAL





---

## IMPORTANT

**Please read this manual carefully before using the crane scale.**

### Table of content

Safety guide-----	2
Chapter 1. Product Description -----	3
Chapter 2. Use Method-----	3
2.1 Information on the panel-----	3
2.2 Operation-----	4
1. Tare-----	4
2. Tare cancel-----	4
3. Accumulation function-----	4
4. To check the weights and times accumulated-----	4
5. Zero-----	5
6. Accumulation clear-----	5
Chapter 3. Calibration-----	5
3.1 Illustration-----	5
3.2 Method-----	5
Chapter 4. Display Illustration -----	6

---

## Safety guide

**Read carefully the following instruction and advice before using this scale.**

- ◆ Over-loading this scale is harshly prohibited
- ◆ Refrain from long-time loading that could lead to excessive fatigue on loadcell used inside the scale. Excessive fatigue on loadcell would decrease the accuracy and shorten the life of scale.
- ◆ Check the shackle and hook regularly.
- ◆ Check the battery power level before/after use and recharge the scale in time.
- ◆ In order to maximize the battery life, periodic recharging is necessary for scales even not in use for long time.
- ◆ Do not try to repair the scale by yourselves.
- ◆ Use privately attached charger only.
- ◆ The scale can show the cell capacity when power on. For example when U 86 is shown, meaning the current cell capacity is 86%. If the cell capacity is 20%, please charge the scale as soon as possible to avoid damaging the battery.

---

## Chapter 1. Product Description

C9 digital electronic crane scale is high accuracy, one-side direct display measuring unit which combines load cell and power supply together. It can be directly hung on the hook of a hoist and ensure the scale to complete the tasks of loading and weighing goods synchronously. The screen is made up of super-bright tube (LED), which can be easily seen in 25 meters. The scale body is made of strong alloy aluminum. The structure is compact and operation is quite easy.

**The product is equipped with wireless communication, ranged up to 500m with data transmission.**

**Chart 1-1 Main technical characters**

<b>Accuracy</b>	<b>OIML III</b>
<b>Taring range</b>	<b>100% FS</b>
<b>Result steady display</b>	<b>3~7 Seconds</b>
<b>Alarm of over weight</b>	<b>110% FS</b>
<b>Max safe load</b>	<b>125% FS</b>
<b>Limit coefficient</b>	<b>4</b>
<b>Power supply</b>	<b>Full seal airtight recharge battery 6v/10AH</b>
<b>Display tube</b>	<b>Super-bright LED or LCD(height 30mm/5 bits)</b>
<b>Working temperature range</b>	<b>-10°C~+40°C</b>
<b>Remote controller distance</b>	<b>≤20m</b>

## Chapter 2. Use Method

### 2.1 Information on the panel

- (1) In the different status, different information is showed. User can operate scale according to the notes showed on displayer.
- (2) The light on upper right to the displayer means the charging of the battery. It'll be on when charging the scale.
- (3) The light on the left side indicates stable status. When the scale becoming stable during operating, the light will be on.

---

(4) View of outline of figure:



(5) View of remote controller:



## 2.2 Operation:

### Explanation of key-press:

Key-press	Explanation	Key-press	Explanation
<b>0(FUNC)</b>	Setup Parameter	<b>4(←)</b>	Turn left
<b>5(Confirm)</b>	To confirm	<b>6(→)</b>	Turn right
<b>*(Zero)</b>	Zero	<b>2(↑)</b>	Digit minus1
<b>#(Accu)</b>	Accumulate	<b>8(↓)</b>	Digit add 1

#### 1. Tare:

In the normal weighing status, press [Tare] and displays “0”.

#### 2. Tare cancel:

In the status of tare, press [Tare] again to cancel.

#### 3. Accumulation function:

Press [Accu] on the remote controller can accumulate the current weights. After pressing [Accu] it displays “N—XX” → “H XX” → “L XXXX” automatically then back to weighing status. “N—XX” means the times of accumulation, “H XX”+“L XXXX” is total weight of accumulation. (After pressing [Accu] every time, the value of N will be added 1.)

#### 4. Accumulation clear:

The max time of accumulation is 99, it'll display N—OF if exceed, please clear the current accumulation at that time. Press [Zero] during accumulation station, which will be cleared.

#### 5. Zero:

In normal weighing status, press [Zero] to setup “0”.

#### 6. [Func] usage:

Press [Func] can setup parameter, press [Enter] it displays code of parameter.

### List of Code

Code	Explanation	Code	Explanation
09	Calibration	08	Check inner code
07	Wireless Communication Mode	06	Wireless Communication Mode Canceled

Press “↑” “↓” “←” “→” to choose and adjust.

**Note: Wireless communication mode is not default equipment.**

**The scale has power saving mode, it'll enter power saving mode after 30mins during stable status and power off after 2 hours.**

## Chapter 3. Calibration

### 3.1 Illustration:

When scale is stable, press [Func] and press [Enter], it displays parameter code XX. Press “↑” “↓” “←” “→” to choose code 09 and press [Enter], which displays “SET” and entering calibration status.

Step 1: Setup parameter (e.g.: Max capacity 5t, standard weights 4t)

After displaying “---SET---”, operate as table 3-1 as followed.

Table 3-1 Operation of Step 1

Step	Operation	Display	Explanation
1		---SET---	Status of parameter setup
2	Press [Enter]	d 1	Displaying current division value
3	Press “←” or “→”	d 2	Choose division value: 0.1, 0.2, 0.5, 1, 2, 5, 10, 20, 50 optional (2 is default division value for 5t crane scale)
4	Press [Enter]	00000	Setup F.S.
5	Press “↑” “↓” “←” “→”	05000	Input F.S.
6	Press [Enter]	---CAL---	Finished setting; entering calibration.

Step 2: Calibration, operate as table 3-2 as followed.

Table 3-2 Operation of Step 2

Step	Operation	Display	Explanation
1		---CAL---	Status of calibration of weight
2	Press [Enter]	UloAd	Wait until the light of stable on
3	Press [Enter]	05000	Displaying F.S.
4	Load weights (e.g.: 4t)		
5	Press “↑” “↓” “←” “→”	04000	Input 4000kg
	Press [Enter]	4000	Calibration finishes, displaying current weight.

## Chapter 4. Display Illustration

No.	Display	Illustration
1	FULL	Attention of overweight
2	U 86	Current cell capacity
3	N---XX	Times of accumulation
4	N---oF	Accumulated times exceed
5	AddoF	Accumulated weight exceed
6	LJoFF	Clear accumulation
7	--SET--	Status of setting up division value
8	--CAL--	Calibration status
9	--Ad--	Check the status of AD
10	ULoAd	Zero position status











**Gram Precision S.L.**

**Travesía Industrial, 11 · 08907 Hospitalet de Llobregat · Barcelona (Spain)**

**Tel. +34 93 300 33 32**

**Fax +34 93 300 66 98**

**comercial@gram.es**

**www.gram-group.com**